

AUTOMOTIVE 1K PAINT SYSTEM

Repairs & Old Paint



CHECKLIST

- 80-180g & 320-600g
- Sandpaper
- Wax & Grease Remover
- Tack Cloth
- Clean Rags
- Gravity or Pot Spray Gun
- Respirator
- Gloves
- Masking Film
- Masking Paper
- Masking Tape
- Filler
- Filling Blades
- Thinners
- Mixing Cups

Contact Versatile Paints & Adhesives for professional industry advice

LECHLAR: Colours to be selected from colour chart

CONCEPT: Colours to be selected from No Mix Base. Colours may be automotive.

STEP 1

Sand with 80-180g sandpaper



STEP 2

Wipe with Wax & Grease Remover



STEP 3

Apply 2-4x coats of Primer Surface Filler either:

- Colorpak (Aerosol)
- AutoGuard (Spray)



STEP 4

Sand with 320-600g sandpaper



STEP 5

Wipe with Wax & Grease Remover



STEP 6

Apply 2-5x coats of Topcoat of either:

- Lechlar L29180 Lacquer
- Concept 302 Enamel
- No Mix Basecoat

DISCLAIMER: This guide has been produced with proper care, however the advice and recommendations offered within is general in nature and is subject to change without notice. Versatile is not responsible for the application of the advice offered and takes no responsibility for the accuracy or completeness of it. Versatile strongly suggest the Applicator carries out their own testing to ensure the products and processes achieve the desired result.

13 St John Street Tauranga
07 577 0195
orders@versatileproducts.co.nz
versatileproducts.co.nz

 **versatile**
PAINTS & ADHESIVES